

Installing, Running and Activating U.P.M.A.C.S. Operate v6.2.3

- To install U.P.M.A.C.S., you may to have Administrator privileges on your computer. If you are not an Administrator, log off, and log back on as an Administrator. For information about Windows 7/10 or Windows 2012 Server user privileges, please refer to the documentation that came with your computer.
- Insert the installation CD into your CD ROM drive.
- Double-click on the icon labeled "**Install_UPMACS.exe**". The U.P.M.A.C.S. install program will guide you through the installation step by step.
- U.P.M.A.C.S. is now installed and can be started from Start Menu
- You may sign-on in UPMACS Operate using *testuser* for both the user-name and password. This temporary user account may be deleted later once you create your own user data base.



The U.P.M.A.C.S. Operate Program

Once U.P.M.A.C.S. is installed, you will be able to run it as a fully functioning program for **10 days**. After this period you must activate UPMACS Operate. Clicking on "**Activate UPMACS Operate**" will provide you with two **User Codes**. These two **User Codes** must be emailed to support@upmacs.com. You will then receive an email with an **Activation Code**. **You can then enter this activation code** which will activate a perpetual UPMACS Operate license on the computer where UPMACS Operate was installed.

