



Installing, Running and Activating U.P.M.A.C.S. Operate and Develop Software v6.2.4

- To install U.P.M.A.C.S., you may have to have Administrator privileges on your computer. If you are not an Administrator, log off, and log back on as an Administrator.
- Download UPMACS installation ZIP file from UPMACS web site http://upmacs.com/wp-content/uploads/2016/05/UPMACS_Installation-2025-A.zip
- *Unzip all files into a unique folder possibly off of Downloads folder.*
- Right-click on file "**Install_UPMACS.exe**" and select **Run as Administrator**. The U.P.M.A.C.S. install program will guide you through the installation step by step. IMPORTANT: Be sure to select option to install both Operate and Develop software.
- U.P.M.A.C.S. is now installed and can be started from Start Menu. IMPORTANT: Right-Click on *Operate_System.exe* and select **Run as Administrator**.
- You will be prompted once first time to select an UPMACS Log file. This file will contain any and all UPMACS Operate events. Just enter any name for now. This can be changed later.
- You may sign-on in UPMACS Operate using *testuser* for both the user-name and password. This temporary user account may be deleted later once you create your own user database

-  Operate_System
-  Development_System



Once U.P.M.A.C.S. is installed, you will be able to run it as a fully functioning program for **10 days**. **IMPORTANT:** Right-Click on Operate or Develop and select **Run as Administrator**. After this 10 day period you must activate UPMACS Operate or Develop. Clicking on "**Activate UPMACS Operate/Develop**" will provide you with two **User Codes**. These two **User Codes** must be emailed to **support@upmacs.com**. You will then receive an email with an **Activation Code**. **You can then enter this activation code** which will activate a perpetual UPMACS Operate or Develop license on the computer where UPMACS was installed.